

Pöttinger - Trust creates Affinity - since 1871

"Quality pays for itself." Therefore we apply the highest quality standards to our products which are constantly monitored by our in-house quality management and our management board. Because the safety, perfect function, highest quality and absolute reliability of our machines in operation are the core competencies for which we stand.

There may be deviations between these instructions and the product as we are constantly developing our products. Therefore no claims may be derived from the data, illustrations and descriptions. Please contact your Specialist Service Centre for any binding information about specific features of your machine.

We would ask you to please understand that changes to the scope of supply with regard to form, equipment and technical specifications are possible at any time.

Any form of reprint, translation or reproduction, including excerpts, requires the written approval of Pöttinger Landtechnik GmbH.

All rights according to copyright laws remain expressly reserved by Pöttinger Landtechnik GmbH.

© Pöttinger Landtechnik GmbH – 31st October 2012

Product liability, information obligation

Product liability obliges manufacturers and dealers to issue operating instructions for the machine at the point of sale and to instruct the customer on the operation, safety and maintenance regulations governing the machine.

A confirmation is required to verify that the machine and operating instructions have been handed over correctly.

For this purpose

- **Document A** is to be signed and returned to Pöttinger or via the internet to www.poettinger.at
- **Document B** remains with the specialist dealer handing over the machine.
- **The customer receives document C.**

For the purposes of product liability law, every farmer is an entrepreneur.

In the terms of product liability law, damage to property is any damage arising due to the machine, but not to the machine, and an excess (500 euros) exists for this liability.

Corporate damage to property within the terms of the product liability law is excluded from this liability.

Be advised! The operating instructions must also be handed over with any subsequent machine sale or transfer and the transferee must be instructed in the regulations stated.

Refer to PÖTPRO for additional information about your machine:

Are you looking for suitable accessories for your machine? No problem! All the information you require is here at your disposal. Scan the QR code on the machine's type plate or look under www.poettinger.at/poetpro

And if we don't have what your looking for, then your Specialist Service Centre is there for you with help and advice.

INSTRUCTIONS FOR PRODUCT DELIVERY



PÖTTINGER Landtechnik GmbH
Industriegelände 1
A-4710 Grieskirchen
Tel. 07248 / 600 -0
Telefax 07248 / 600-2511

According to the product liability please check the above mentioned items.

Please check. ☒

- ☐ Machine checked according to delivery note. All attached parts removed. All safety equipment, drive shaft and operating devices at hand.
- ☐ Operation and maintenance of machine and/or implement according to operating instructions explained to the customer.
- ☐ Tyres checked re. correct pressure.
- ☐ Wheel nuts checked re. tightness.
- ☐ Drive shaft cut to correct length.
- ☐ Correct power-take-off speed indicated.
- ☐ Fitting to tractor carried out: to three-point linkage
- ☐ Trial run carried out and no defects found.
- ☐ Functions explained during trial run.
- ☐ Pivoting in transporting and operating position explained.
- ☐ Information given re. optional extras.
- ☐ Absolute need to read the operating manual indicated.

In order to prove that the machine and the operating manual have been properly delivered, a confirmation is necessary.
For this purpose please do the following:

- sign the **document A** and send it to the company Pöttinger or via the internet to www.pottinger.at
- **document B** stays with the specialist factory delivering the machine.
- **document C** stays with the customer.



Safety hints to observe in supplement!

Table of contents

WARNING SIGNS

CE sign	5
Meaning of warning signs	5

HITCHING IMPLEMENT TO TRACTOR

Hitching implement to tractor	6
-------------------------------------	---

DISMOUNTING IMPLEMENT FROM TRACTOR

Dismounting implement from tractor	8
Parking in the open	8

TRANSPORT POSITION

Transport position (T)	9
Starting position	9
Changing to transport position	9
Road Transport	10
Lighting during use on roads	10

WORKING POSITION

Working position	11
Changing to working position	11

STARTING WORK

Important points before starting work	12
Safety hints	12
Turning manoeuvre when mowing	12

WORKING ON SLOPES

Take care when turning on slopes!	13
---	----

MOWING

Mowing	14
Reversing	14
General guidelines for working with the implement	14
Anti-collision device	14
Note	15
Fitting optional equipment	16

SWATHFORMER

Swath Disc	17
Conveyor drums (Optional extra)	17
Flat cone conveyor (Optional extra)	17
Safety advice	18
General maintenance information	18
Cleaning of machine parts	18

MAINTENANCE

Parking in the open	18
Winter storage	18
Cardans	18
Hydraulic unit	18
Oil level check, angular gear	19
Angular gear oil change	19
Cutter bar oil level check	20
Cutter bar oil change	21
Installing cutter blades	21
V-belt drive	22
Checking wear on mowing blade holders	23
Holder for a quick change of cutter blades	24
Checking the mowing blade suspension	24
Changing the Cutter Blades	24
Changing the Cutter Blades (from 2004 model)	25
Storing the lever	25


TECHNICAL DATA

Technical data	26
The defined use of the mower unit	26
Optional equipment:	26
Necessary connections	26
Position of Vehicle Identification Plate	26

SUPPLEMENT

Lubrication chart	33
Lubricants	35
Attachment variations	38
Repairs to the cutter bar	40
Assembly instructions	41
Combination of tractor and mounted implement	44

CE sign



The CE sign, which is affixed by the manufacturer, indicates outwardly that this machine conforms to the engineering guideline regulations and the other relevant EU guidelines.

EU Declaration of Conformity (see supplement)


By signing the EU Declaration of Conformity, the manufacturer declares that the machine being brought into service complies with all relevant safety and health requirements.



**Recommendations
for work safety**

**All points referring
to safety in this
manual are
indicated by this
sign.**

Meaning of warning signs




Danger - flying objects; keep safe distance from the machine as long as the engine is running.




Stay clear of swinging area of implements




Wait until all machine components have stopped completely before touching them.




Close both side protective coverings before engaging p.t.o..



Stay clear of mower knife area as long as tractor engine is running with PTO connected.



Never reach into the crushing danger area as long as parts may move.



Shut off engine and remove key before performing maintenance or repair work.



Safety hints:


see Attachment A1 8a. - h.)

Hitching implement to tractor


1. Setting the lower linkage of the lifting mechanism horizontal

2. Lock the implement at the 3-point headstock.


- Attach the mower so that the distance between the inner mower disc and the tractor tyres is 0 - 10 cm.



- Adjust the lower link bolts (1) on the bearing frame according to the three-point category and the track width using the fixing screw. The mower must not touch the rear tractor tyres.





Ensure that you use the required hole (see Figure below) on the bolt with the fixing screw! Otherwise the mower may loosen from the coupling, fall to the ground and cause damage to property.



- See information in the Attachment to these Operating Instructions for dual wheels or specially wide tyres

3. Connect hydraulic plug connector (DW)


DW = dual-action hydraulic connection




4. Position flap release rope (S) in the tractor cabin.

5. Adjust upper linkage spindle

- The mower is positioned horizontal or slightly forwards by turning the upper linkage spindle (16).




6. Secure lower linkage (4) against lateral movement.



7. Fold up support stand (5) and secure.

- The implement is now completely hitched to the tractor.
- The cardan shaft length is to be checked and adjust if necessary prior to first operation.


(See Chapter "Adjusting the cardan shaft" in Attachment B).



Dismounting implement from tractor



1. Raise stop-lock support rope (S)

- Stop-lock support to position "B"



2. Lower cutter bar hydraulically to the ground

- actuate servo-valve (ST)
- release the rope (S) during lowering



3. Swing support stand down and secure (F)

4. Lower implement to the ground using lifting gear.



5. Dismount implement from tractor



Safety note!

Before dismounting, check the locking device properly (F), otherwise danger of tipping!

- disconnect hydraulic lines
- disconnect upper link



- remove rope from tractor cabin
- disconnect lower link
- disconnect drive shaft and lay it down (GW)


Parking in the open

When parking in the open for long periods of time, clean plunger rods and then coat with grease.



Note

A rusty plunger rod can damage cylinder's sealing elements.




At season's end

- clean plunger rod and all other shiny parts, then grease them
- pay attention to the hints in chapter "MAINTENANCE"

Transport position (T)

Safety Precaution!

see supplement-A1 points 7.), 8c. - 8h.)



NOVADISC 225, 265, 305, 350

NOVADISC 400



Changing from working position to transport position is only to be carried out on even, firm ground.

Never let the mowing mechanism run with the mower raised.



- Before you leave the tractor, lower the machine on to ground!

Starting position

Implement is attached to tractor

- see chapter "Attaching implement to tractor"

Support stand swung up and secured.




Changing to transport position

1. Fold front protection covers back (1).

This is necessary with many tractor types. It prevents damage to the rear window or the mud guard later on when raising the mower bar.


2. Raise stop-lock support using the rope (S).

- stop-lock support to position "B"



3. Raise cutter bar hydraulically


- actuate servo-valve (ST)



- release rope (S) during raising
- let stop-lock support engage (T1)


4. Briefly move servo-valve (ST) into "LOWER" position (S)

This enables stop-lock support to sit firmly in the catch (T1) and secures cutter bar in the raised position (T)



Road Transport

- Observe the regulations issued by your country's legislative body.
- Travelling on public roads may only be undertaken as is described in the chapter "Transporting Position".
- Fasten lower hydraulic link so that implement cannot swing out sideways.




NOVADISC 225, 265, 305, 350

Lighting during use on roads

If desired, a lighting unit can be supplied (1).

For single parts see spare parts list.

- Connect lighting and raise appliance for transport.



NOVADISC 400

Working position



Safety Precaution!

see supplement-A1 Pkt. 7.), 8c. - 8h.)

Changing from transport position to working position is only to be carried out on even, firm ground.



- Make sure that swivel area is free and that nobody is standing in the danger area.



bab 449 567

Starting position for lowering the cutter bar

1. Implement is attached to tractor
- see chapter "Attaching implement to tractor"
2. Cutter bar in transport position
3. Support stand swung up and secured




TD 121-02-07

Changing to working position

Swinging the cutter bar down.

1. Raise stop-lock support using rope (S)
- Put hydraulic control device (ST) briefly at "lift", in so doing the fixing of the stop-lock support is eased in the catch.
- Stop-lock support to position "B"
2. Lower cutter bar hydraulically to the ground
- Move hydraulic control valve (ST) to the "LOWER" position (S)




- release rope (S) during lowering
- Move hydraulic control valve (ST) to the "FLOAT POSITION" (only with double-action hydraulic control valve)

3. Set height of lifting gear (H1)

This lifting gear position (H1) does not need to be changed when mowing or turning (see next page).


Using the tractor's lifting gear, raise or lower the implement until a gap of about (H1 = 0) is achieved.



122-02-14

Adjusting the floor bearing load of the mowing bar


- | | |
|--------|---------------------------|
| H1 = 0 | Carry out basic setting |
| H1 + | Decrease bearing pressure |
| H1 - | Increase bearing pressure |



495.757 neu

4. Close front protection covers (5a)

- Operation only with closed protection covers.



TD 39/96/9

5a

Important points before starting work



Safety hints:

see supplement-A Pkt. 1. - 7.)

After the first hours of operation

- Retighten all knife screw fittings.

Safety hints

1. Check

- Check the condition of knives and the knife holder.
- Check cutting drums for damage (see also chapter "Maintenance").


2. Switch-on the machine only in working position and do not exceed the prescribed power take-off speed (for example max. 540 rpm).

A transfer, which is located near the gear, advises which p.t.o. speed your mower unit is equipped for.



- Turn the p.t.o. on only when all safety devices (coverings, protective aprons, casings, etc.) are in proper condition and attached to the implement in the correct protective positions.

3. Pay attention to correct p.t.o. direction of rotation!




4. Damage protection!

- The surface to be mowed must be free of obstructions or foreign objects. Such objects (e.g. large stones, pieces of wood, boundary stones, etc.) can damage the mower unit.



In the event of a collision

- Stop immediately and switch off the drive.
- Carefully check the implement for damage. The mowing discs and their drive shaft must be checked in particular (4a).
- Have the implement checked also by a specialist workshop if necessary.




After any contact with foreign objects

- Check the condition of knives and the knife holder.
- Retighten all knife screw fittings.

5. Stay clear while engine is running.

- Keep people out of the danger zone - foreign bodies which can be ejected by the mower could injure them.
- Special care is necessary on or near stony ground.



6. Wear hearing protection

The noise level in the workplace can deviate from the measured value (see Technical Data) partly because of the differing cabin types of various tractors.




- If a noise level of 85 dB (A) is reached or exceeded, the farmer must have suitable hearing protection in readiness (UVV 1.1 §2).
- If a noise level of 90 dB (A) is reached or exceeded, the hearing protection must be worn (UVV 1.1 § 16).

Turning manoeuvre when mowing

The cutter bar can be raised hydraulically (22°).

- The drive must not be turned off to do this.
- The lifting gear's (H1) position does not need to be altered when turning.



Attention!

Do not enter the mower unit area as long as the drive is running.


Take care when turning on slopes!



The tractor's travelling characteristics are influenced by the weight (G) of the mower unit. This can lead to dangerous situations, especially on slopes.

Danger of tipping occurs

- when the mower unit is facing downhill and in a raised position,
- when travelling in a left-hand curve with the mower unit raised,
- when travelling in a left-hand curve in the transport position (mower unit completely raised).





Note:

Raise the mower when reversing!


Safety information

- Reduce speed in left-hand curves accordingly.
- Travel so that the raised mower unit is facing uphill.
- It is better to travel in reverse on a slope than to carry out a risky turning manoeuvre.



Mowing


1. Set the lower link of the hoist horizontally (Sp)



2. Set cutting height by turning the upper link spindle (16)

- max. 5° mower discs inclination

3. Set height (H1) of hoist



Set the ground bearing load of the mower bar

H1 = 0 basic position

H1 + reduce bearing pressure

H1 - increase bearing pressure

4. For mowing, slowly engage the p.t.o. shaft away from the crop and bring the mower rotor up to full speed.

Smoothly increasing the p.t.o. speed will avoid system-related noises from the p.t.o. free-wheel.

- The driving speed depends on the ground conditions and the crop to be mown.

5. Hydraulic servo-valve (ST)


- Single-action hydraulic control valve (ST) on "LOWER"
- Double-action hydraulic control valve (ST) on "Floating position"

Reversing

Raise the mower when reversing!

General guidelines for working with the implement

- The mower unit is suitable for an upward inclination of 22° resp. downward 30° angle of repose.



Anti-collision device


When mowing around trees, fences, boundary stones etc., collisions between the cutter bar and obstacles can occur despite careful and slow driving. So in order to prevent such damage, an anti-collision device has been provided for the mower.

Beware! It is not the purpose of the collision safety device to prevent damage to the machine when working at full speed.

- The overload safety (34) allows the mower bars to swivel back when running into an obstacle.
- If you drive backwards, the overload safety snaps back in.

Setting:

If the impact safety is too little operated, the hexagonal nut can be twisted.



Setting

values:

NOVADISC 225	=	127 mm
NOVADISC 265	=	120 mm
NOVADISC 305	=	116 mm
NOVADISC 350	=	112 mm
NOVADISC 400	=	108 mm

If you are not sure whether the cutting area is really free of obstacles, please work at an appropriate slow speed!


Note




If under difficult operation conditions (e.g. very long grass, low driving speed, mowing in hilly areas) strut A displays failures (crop accumulation), these can be removed with the types Nova Disc 225 and 265. For the types 305, 350 and 400 this is not allowed!



If you need to use one or two swath formers on the right side, this strut must stay mounted for all types, it may not be removed!

In addition, when operating under difficult conditions, you can attach a crop divider (1) so as to turn away the grass that is drawing in.




Fitting optional equipment






Swath Disc

With the swath disc a narrower swath is formed when mowing. This prevents them from being run over by the tractor's wide tyres.



Conveyor drums (Optional extra)

With the both conveyor drums two narrower swaths is formed when mowing. This prevents them from being run over by the tractor's wide tyres.




Flat cone conveyor (Optional extra)

Flat cone conveyors are recommended:

- to improve the conveyance rate of swath deposits, particularly with heavy, thick fodder components
- For individual parts see Spare Parts List

Safety advice

- Switch off engine prior to any adjustment, maintenance or repair work.



General maintenance information

Please observe the information below to maintain the implement in good condition even after a long period in operation:

- Re-tighten all bolts after the first hours in operation.

The following should be checked in particular:

- Blade bolt connections at mower
- Tine bolt connections at rake and tedder




Spare parts

- Original parts and accessories are specially designed for the implements.
- We expressly point out that we have not tested or approved any original parts and accessories not supplied by us.
- The installation and/or use of such products may under certain circumstances negatively modify or impair the properties of the implement as specified in the design. Any liability on the part of the manufacturer is excluded in the event of any damage due to the use of non-original parts and accessories.
- Any unauthorised modifications or the use of components and attachments at the implement rules out any liability on the part of the manufacturer.

Cleaning of machine parts


Be advised! Do not use high-pressure washers for the cleaning of bearing- and hydraulic parts.

- Danger of rust!
- After cleaning, lubricate the implement according to the lubrication plan and perform a brief test run.
- Cleaning pressure being too high may damage the paint.



Parking in the open

Clean and protect the piston rods with grease prior to longer periods parked outside.



Winter storage

- Clean implement thoroughly prior to winter storage.
- Put up protection against weather.
- Change or top up gear oil.
- Protect exposed parts from rust.
- Lubricate all greasing points according to lubrication chart.
- Disconnect terminal, store dry and protected from frost.

Cardans

- See information in Attachment


Please observe the following for maintenance!

The instructions in these Operating Instructions apply. If no particular instructions are available here, then the information in the instructions supplied by the respective cardan shaft manufacturer apply.

Hydraulic unit

Caution injury and infection hazard!

Liquids discharging at high pressure may penetrate the skin. Therefore seek immediate medical help!



Make sure that the hydraulic system is suitable for the tractor before connecting the hydraulic lines.

After the first 10 hours in operation and thereafter every 50 hours in operation

- Check hydraulic unit and piping for leaks and if necessary re-tighten bolt connections.

Prior to every taking into operation

- Check hydraulic hoses for wear.

Replace any worn or damaged hydraulic hoses immediately. The replacement hoses must meet the manufacturer's technical requirements.

Hose lines are subject to natural ageing. The period of use should not exceed 5 – 6 years.



Safety advice

- Switch off engine and remove ignition key prior to any adjustment, maintenance or repair work.
- Only perform work underneath the implement with secure supports.
- Re-tighten all bolts after the first hours in operation.
- Only park implement on flat, firm ground.



Repair information

Please observe the repair information in the Attachment (If available).



Safety advice

Clean the coupling plug of the hydraulic hoses and the oil socket prior to each connection.


Note any abrasion and clamping points.

Oil level check, angular gear

- Change oil after the first 50 operating hours.
Under normal operating conditions, oil is to be replenished annually (OIL LEVEL).
- Change oil after 300 ha at the latest.

Oil quantity:


0.95 litre SAE 90



Angular gear oil change

1. Raise cutter bar and bring into vertical position.

- See transport position.



2. Place suitable container underneath.

3. Remove hex head bolt (E) completely and allow old oil to run out.

- Dispose of old oil properly.

4. Lower cutter bar and bring into horizontal position.

- See working position.

5. Close discharge opening again with hex head bolt (E).

6. Fill oil (E).



• Too much oil causes the overheating of the transmission during operation.

• Too little oil does not ensure the required lubrication.¹⁾

Cutter bar oil level check

- Under normal operating conditions, oil is to be replenished annually.



Caution


Cleaning and maintenance works shall be performed only with the machine turned off and the mowing units lowered.

1. Lift one side of the mower bar X3 and support it.

$$X3 = X2 + X1$$

X1 = Distance from ground to vats upper edge.

X2 = Distance from vats upper edge left to vats upper edge right.



NOVADISC 400: X2 = 220 mm


- The side where the oil refill screw is located remains on the ground.
- Lift the other side of the mower bar about X1 and support with a suitable prop.

2. Leave mower bar in this position for about 15 minutes.

- This time is necessary to allow the oil to collect in the lower area of the mower bar.

3. Remove oil fill screw (63).

Measure oil level through the opening (63).




4. Oil level check




Important information when measuring the oil level:

You jack up the cutter bar depending on the length.

The cutter bar width must be adjusted in precise horizontal position. (see image).



The oil level is correct if the gear oil reaches the lower edge of the level opening (63) (OIL LEVEL).



5. Topping up oil

Complete with the missing oil quantity.



Note


- Too much oil can cause the cutter bar to overheat during operation.
- Too little oil does not guarantee the necessary lubrication.

Cutter bar oil change

- Change oil after the first 50 operating hours or after 100 ha at the latest.

Note:







- Change oil when at operating temperature.
The oil is too viscous when cold. Too much old oil remains stuck to the gearwheels and thus any suspended matter present cannot be removed from the gearing.



Oil quantity

NOVADISC 400: 4.4 lire SAE 90

- Raise the lifting mechanism of the tractor completely.
- Hydraulic control unit (ST) to "LOWER".
- The cutter bar must hang down at the edge.
- Take out oil drain plug (62), let oil run out and dispose of waste oil correctly.




Installing cutter blades



Be advised!

The arrow on the cutter blade shows the cutter disc's direction of turn.

- Clean paint off the screw-on surfaces prior to assembly



V-belt drive

- Check V-belt tension:

After 1 hour, after 5 hours, after 20 hours then occasionally.


Adjustment dimension:

0.5 - 3 mm



- Re-tensioning is only required if the adjustment dimension is more than 3 mm.
- If any of the 4 V-belts is damaged or twisted, then all 4 V-belts are to be replaced.

CAUTION!

If the V-belts are too highly tensioned, there is a risk of damage to the ball bearings and the shafts.




Checking wear on mowing blade holders



Wearing parts are:

- mounting of mowing blades (30)
- bolts of mowing blades (31)



Attention!

Danger of accident if wearing parts are worn

If such wearing parts are worn out they must not be used any longer.

Otherwise accidents may be caused through parts that are flinged away (e.g. mowing blades, fragments...)

Process of visual control:

1. remove mowing blades
2. remove grass and dirt
 - around pin (31)



Check the suspension of mowing blades as to wear and other damage:

- every time before bringing the machine into operational use
- several times during use
- immediately after hitting an obstacle (e.g. a stone, piece of wood, metal,...)



Attention !

Danger of accident if:


- the central part of pin of blade must have a minimum of 15 mm
- the wearing area (30a) has reached the edge of the boring
- the pin of the blade is worn in the lower part (30b)
- the pin of the blade is no longer firmly seated



If you notice one or several of these characteristics of wear stop mowing at once!

Worn parts must be replaced by original parts made by Pöttinger immediately !

Screw down the pin of the blade with the nut with 120 Nm.




Holder for a quick change of cutter blades



Attention!
For Your Safety

- Regularly check that cutter blades are tightened firmly!
 - Cutter blades on a cutter disc should wear out simultaneously (danger of imbalance).
Otherwise they are to be replaced with new ones (replace in pairs).
 - Buckled or damaged cutter blades must not be used further.
- Buckled, damaged and/or worn cutter blade holders (30) should not be used further.



Checking the mowing blade suspension

- Normal check every 50 hours.
- Check more often when mowing on stony terrain or in other difficult operating conditions.
- Check immediately after driving over a hard obstacle (e.g. stones, pieces of wood, etc).


Carry out a check

- as described in chapter „Changing the Cutter Blades“



Take note!


Damaged, buckled and worn out parts must not be used further (danger of accident).



Changing the Cutter Blades

(up to 2003 model)

1. Insert lever (H) horizontally between cutter disc and holder (30)



2. Push movable holder (30) down using lever (H).

3. Remove cutter blade (M)

4. Clean forage remains and dirt away.



- around the bolts (31) and inside the borehole (32)

5. Check:

- blade bolts (31) for damage, wear and fitting
- holder (30) for damage, change in position and fitting
- borehole (32) for damage.
 - Side surfaces must not show signs of deformation



6. Fit cutter blades and remove lever (H)

- Put the lever (H) in both the recesses in the tool case.
- Close tool case and secure with spring clip (V).



Changing the Cutter Blades (from 2004 model)


1. Insert lever from left or right side on the cutter disc "Pos A" until it stops.
2. Swing lever from "pos. A" to "pos. B" and push the movable holder (30) down.
3. Remove cutter blade (M)



- blade bolts (31) for damage, wear and fitting
- holder (30) for damage, change in position and fitting
- borehole (32) for damage.
- Side surfaces must not show signs of deformation

6. Install cutter blades

7. Visual check! Check that blade (M) is correctly



4. Clean forage remains and dirt away.
 - around the bolts (31) and inside the borehole (32)
5. Check:

positioned between blade bolts (31) and holder (30) (see diagram).

8. Swivel lever (H) to "A" again and remove.

Storing the lever

- Place lever in the respective holding pouch and secure.
- See diagrams for storage places.

Nova Alpin 226/266



Nova Alpin 226/266 Weiste triangle



Nova Cat 225/ 265 / 305 / 350 / 400



Nova Cat 266F / 306F



Nova Disc 225



Technical data

NOVADISC 400 (Type PSM 389)

Three-point linkage (adjustable)	Kat. III / II
Working width	3,88 m
No. of mowing discs	9
No. of knives per disc	2
Hydraulic lift (single-acting)	
Coverage up to	3,8 ha/h
Max. p.t.o. speed	540 / 1000 min ⁻¹
Weight ¹⁾	min. 717 kg
Required power	ab 58 kW (80 PS)
Free running drive shaft.	
Permanent sound emission level	80,2 dB(A)

¹⁾ Weight: Variations possible depending on machine features.

All data subject to revision.

Optional equipment:

- Warning signs with lighting
- Swath disc
- Flat cone conveyors
- Wearing runners
- High cut runners
- Driving motor speed 540 min⁻¹

Necessary connections

- 1 x double action hydraulic connection
(minimum necessary tractor fitting)
- Operating pressure min.: 150 bar
Operating pressure max.: 210 bar

POTTINGER

Chassis-Nr. xxxxxxxxxxxx

Modell

Type Basisgewicht

Baujahr Modelljahr


Serial-Nr.



Position of Vehicle Identification Plate

The chassis number is engraved on the name plate illustrated on the left. Warranty claims, enquiries and spare parts orders cannot be made without quoting the chassis number.

Please enter the number on the title page of the Operating Instructions immediately on taking delivery of the vehicle/equipment.



The defined use of the mower unit

The

NOVADISC 400 (Type PSM 389)

mower is intended solely for normal use in agricultural work.

- The mowing of grassland and short stemmed fodder.

Any other uses outside of these are regarded as undefined.

The manufacturer takes no responsibility for any resulting damage which occurs henceforth. The risk is carried by the user alone.

- The keeping of operating, service and maintenance requirements layed down by the manufacturer also come under the heading of „defined use“.

SUPPLEMENT

Things will run better with
genuine Pöttinger parts

Original
inside



- **Quality and precise fitting**
 - Operating safety.
- **Reliable operation**
- **Longer lasting**
 - Economy
- **Guaranteed availability** through your Pöttinger Sales Service.

The decision must be made, "original" or "imitation"? The decision is often governed by price and a "cheap buy" can sometimes be very expensive.

Be sure you purchase the "Original" with the cloverleaf symbol!


PÖTTINGER



Recommendations for work safety

All points referring to safety in this manual are indicated by this sign.

1. Operating instructions

- The operating instructions are important for the correct operation of the machine. Make sure that the operating instructions are always on hand when operating the machine.
- Keep the operating instructions as long as the machine is in your hands.
- Pass the operating instructions on to the buyer when selling the machine.
- Make sure that all safety and warning symbols remain attached on the machine and keep them readable. The hazard warnings provide important information for a safe operation and, thus, your safety.

2. Qualified personnel

- Only persons of legal age, mentally and physically able and having been trained or familiarized accordingly must operate this machine.
- Persons not yet trained or familiarized or under training must only operate this machine under the supervision of an experienced person.
- Inspection, setting and repair work must only be performed by authorized persons.

3. Repair work


- These instructions only refer to service, maintenance and repair operations the user is able to carry out without assistance. Any work beyond this scope has to be carried out at authorized workshops only.
- Repairs on the electrical and hydraulic system, preloaded springs, pressure accumulators, etc. require sufficient knowledge, correct tools and protective clothing and, thus, must only be performed at authorized workshops.

4.) Defined use

- See "Technical Data".
- The keeping of operating, service and maintenance requirements laid down by the manufacturer also come under the heading of "defined use".

5.) Spare parts

- The **original components and accessories** have been designed especially for these machines and appliances.
- We want to make it quite clear that components and accessories that have not been supplied by us have not been tested by us.



- The installation and/or use of such products can, therefore, negatively change or influence the construction characteristics of the appliance. We are not liable for damages caused by the use of components and accessories that have not been supplied by us.
- Alterations and the use of auxiliary parts that are not permitted by the manufacturer render all liability invalid.

6.) Protection devices

- All protection devices must remain on the machine and be maintained in proper condition. Punctual replacement of worn and damaged covers is essential.

7.) Before starting work

- Before commencing work, the operator must be aware of all operating devices and functions. The learning of these is too late after having already commenced operation!
- The vehicle is to be tested for traffic and operating safety before each operation.

8.) Asbestos

- Certain sub-supplied components of the vehicle may contain asbestos due to technical reasons. Observe the warning on spare parts.






9.) Transport of persons prohibited

- a. The transport of persons on the machine is not permitted.
- b. The machine may only be driven on public roads when in the position stipulated for road transport.

10.) Driving ability with auxiliary equipment

- a. The towing vehicle is to be sufficiently equipped with weights at the front or at the rear in order to guarantee the steering and braking capacity (a minimum of 20% of the vehicle's tare weight on the front axle).
- b. The driving ability is influenced by ground conditions and by the auxiliary equipment. The driving must be adapted to the corresponding terrain and ground conditions.
- c. When driving through curves with a connected appliance, observe the radius and swinging mass of the appliance.
- d. When travelling in a curve with attached or semimounted implements, take into account the working range and swing mass of the implement!



11.) General

- a. Before attaching implement to three-point linkage, move system lever into a position whereby unintentional raising or lowering is ruled out!
- b. Danger of injury exists when coupling implement to tractor!
- c. Danger of injury through crushing and cutting exists in the three-point linkage area!
- d. Do not stand between tractor and implement when using three-point linkage external operation!
- e. Attach and detach drive shaft only when motor has stopped.
- f. When transporting with raised implement, secure operating lever against lowering!
- g. Before leaving tractor, lower attached implement to the ground and remove ignition key!
- h. Nobody is to stand between tractor and implement without tractor being secured against rolling using parking brake and/or wheel chocks!
- i. For all maintenance, service and modification work, turn driving motor off and remove universal drive.


12.) Cleaning the machine

- a. Do not use high-pressure washers for the cleaning of bearing- and hydraulic parts.



Matching driveshaft to tractor


To determine the actual length required, hold the two halves of the driveshaft side by side.



TD1 4/89/61

Trimming procedure


- To adjust the length, place the pto halves in the shortest operating position (L2) next to one another and mark.



03-291-37


Caution!

- Note the maximum operating length (L1)
 - Aim at the maximum possible tube superimposition (min. 1/2 X)
- Trim the inner and outer protective tube equally
- Attach overload fuse (2) at the implement!
- Always check that drive shaft locks are securely engaged before starting work.



Safety chain

- Use chain to prevent tube guard from rotating. Ensure sufficient swivel space for the cardan shaft!
- Trim the safety chain so that it cannot wind around the cardan shaft.




TD41/88/71

Instructions for working

The permissible pto speed may not be exceeded when using the implement.

- The hitched implement may continue to run after the pto is switched off. Work may only be performed once it has reached complete standstill.
- The cardan shaft must be put down or secured using a chain when the implment is parked. Do not use safety chain (H) to suspend the cardan shaft.



TD41/88/71


Wide-angle joint:

Maximum angle in operation and at standstill 70°.

Standard joint :

Maximum angle at standstill 90°.

Maximum angle in operation 35°.




Maintenance

Replace work covers immediately.

- Lubricate with a brand-name grease before starting work and every 8 hours worked.
- Before any extended period of non-use, clean and lubricate driveshaft.

For winter working, grease the tube guards, to avoid them freezing together.





Information on function when using a cam shifting clutch.

This overload clutch switches the torque transmitted to zero if overloaded. To revert to normal operation, stop the p.t.o. drive briefly.

The clutch reengages at a speed below 200 rpm.



Be advised!


Re-engaging is also possible by decreasing the p.t.o. r.p.m.

TAKE NOTE!

The overload clutch on the driveshaft is not a "Full up" indicator. It is purely an overload protection device designed to protect your vehicle against damage.

Sensible driving avoids frequent engaging of the clutch and prevents unnecessary wear to the clutch and the implement.

Greasing interval: 500 hrs (Special lubricant)





Important for driveshafts with friction clutch

Torque is limited with overloading and brief torque peaks and evenly transferred during slipping.

Prior to initial operation and after long periods out of use, check friction clutch for proper function.

- Measure dimension „L“ at compression spring of K90, K90/4 and K94/1 or at set screw of K92E and K92/4E.
- Loosen screws to release the pressure on the friction disk.
Slip the clutch.
- Tighten set screws to dimension "L".

Clutch is ready for use.



Lubrication chart

X^h after every X hours operation

40 F all 40 loads

80 F all 80 loads

1 J once a year

100 ha every 100 hectares

BB if necessary



GREASE



Oil



= Number of grease nipples



= Number of grease nipples

(III), (IV) see supplement „Lubrificants“

[l] Litre

— — — — Variation




See manufacturer's instructions



Rotations per minute



Always screw in measuring stick up to stop.



Edition 2013

The performance and the lifetime of the farm machines are highly depending on a careful maintenance and application of correct lubricants. our schedule enables an easy selection of selected products. The applicable lubricants are symbolized (eg. "III"). According to this lubricant product code number the specification, quality and brandname of oil companies may easily be determined. The listing of the oil companies is not said to be complete.




Gear oils according to operating instructions - however at least once a year.




- Take out oil drain plug, let run out and duly dispose waste oil.

Before garaging (winter season) an oil change and greasing of all lubricating points has to be done. Unprotected, blanc metal parts outside (joints, etc.) have to be protected against corrosion with a group "IV" product as indicated on the reverse of this page.

Corrosion protection: Fluid 466

Lubricant indicator	I	(II)	III	HFETT (IV)	V	VI	VII
required quality / level niveau	HYDRAULIKÖL HLP DIN 51524 Teil 2	motor oil SAE 30 according to API CD/SF	gear oil SAE 90 resp. SAE 85 W-140 according to API-GL 4 or API-GL 5	lithium grease	transmission grease	complex grease	gear oil SAE 90 resp. SAE 85 W-140 according to API-GL 5
	See notes: * ** ***						

Company	I				V	VI	VIII	NOTATIONS
AGIP	OSO 32/46/68 ARNICA 22/46	MOTOROIL HD 30 SIGMA MULTI 15W-40 SUPER TRACTOR OIL UNIVERS. 15W-30	ROTRA HY 80W-90/85W-140 ROTRA MP 80W-90/85W-140	GR MU 2	GR SLL GR LFO	-	ROTRA MP 80W-90 ROTRA MP 85W-140	* The international specification J 20 A is necessary for compound operation with wet brake tractors. ** HLP-(D) + HV hydraulic oils *** HLP + HV hydraulic oils with a vegetable oil basis, biodegradable and therefore environmentally friendly.
ARAL	VITAM GF 32/46/68 VITAM HF 32/46	SUPER KOWAL 30 MULTI TURBORAL SUPER TRAKTORAL 15W-30	GETRIEBEÖL EP 90 GETRIEBEÖL HYP 85W-90	ARALUB HL 2	ARALUB FDP 00	ARALUB FK 2	GETRIEBEÖL HYP 90	
AVIA	AVILUB RL 32/46 AVILUB VG 32/46	MOTOROIL HD 30 MULTIGRADEHDC 15W-40 TRACTAVIA HF SUPER 10 W-30	GETRIEBEÖL MZ 90 M MULTIHYP 85W-140	AVIA MEHRZWECKFETT AVIA ABSCHMIERFETT	A V I A L U B GETRIEBEFLEISSFETT	A V I A L U B SPEZIALFETT LD	GETRIEBEÖL HYP 90 EP MULTIHYP 85W-140 EP	
BAYWA	HYDRAULIKÖL HLP 32/46/68 SUPER 2000 CD-MC * HYDRA HYDR. FLUID * HYDRAULIKÖL MC 530 ** PLANTO HYD 40N ***	SUPER 2000 CD-MC SUPER 2000 CD HD SUPERIOR 20 W-30 HD SUPERIOR SAE 30	SUPER 8090 MC HYPOID 80W-90 HYPOID 85W-140	MULTI FETT 2 SPEZIALFETT FLM PLANTOGEL 2 N	GETRIEBEFLEISSFETT NLGI 0 RENOLIT DURAPLEX EP 00 PLANTOGEL 00N	RENOPLEX EP 1	HYPOID 85W-140	
BP	ENERGOL SHF 32/46/68	VISCO 2000 ENERGOL HD 30 VANELLUS M 30	GEAR OIL 90 EP HYPOGEAR 90 EP	ENERGREASE LS-EP 2	FLIESSFETT NO ENERGREASE HTO	OLEX PR 9142	HYPOGEAR 90 EP HYPOGEAR 85W-140 EP	
CASTROL	HYSPINAW32/46/68HYSPIN AWH 32/46	RX SUPERDIESEL 15W-40 POWERTRANS	EPX 80W-90 HYPOY C 80W-140	CASTROL GREASE LM	IMPERVIA MMO	CASTROL GREASE LMX	EPX 80W-90 HYPOY C 80W-140	
ELAN	HLP 32/46/68 HLP-M M32/M46	MOTORÖL 100 MS SAE 30 MOTORÖL 104 CM 15W-40 AUSTRORAC 15W-30	GETRIEBEÖL MP 85W-90 GETRIEBEÖL B 85W-90 GETRIEBEÖL C 85W-90	LORENA 46 LITORA 27	RHENOX 34	-	GETRIEBEÖL B 85W-90 GETRIEBEÖL C 85W-140	
ELF	OLNA 32/46/68 HYDRELF 46/68	PERFORMANCE 2 B SAE 30 8000 TOURS 20W-30 TRACTORELF ST 15W-30	TRANSELF TYP B 90 85W-140 TRANSELF EP 90 85W-140	EPEXA 2 ROLEXA 2 MULTI 2	GA O EP POLY G O	MULTIMOTIVE 1	TRANSELF TYP B 90 85W-140 TRANSELF TYP BLS 80 W-90	
ESSO	NUTO H 32/46/68 NUTO HP 32/46/68	PLUS MOTORÖL 20W-30 UNIFARM 15W-30	GEAR OIL GP 80W-90 GEAR OIL GP 85W-140	MULTI PURPOSE GREASE H	FIBRAX EP 370	NEBULA EP 1 GP GREASE	GEAR OIL GX 80W-90 GEAR OIL GX 85W-140	
EVVA	ENAK HLP 32/46/68 ENAK MULTI 46/68	SUPER EVVAROL HD/BSAE 30 UNIVERSAL TRACTOR OIL SUPER	HYPOID GA 90 HYPOID GB 90	HOCHDRUCKFETT LT/ SC 280	GETRIEBEFETT MO 370	EVVA CA 300	HYPOID GB 90	
FINA	HYDRAN 32/46/68	DELTA PLUS SAE 30 SUPER UNIVERSAL OIL	PONTONIC N 85W-90 PONTONIC MP 85W-90 85W-140 SUPER UNIVERSAL OIL	MARSON EP L 2	NATRAN 00	MARSON AX 2	PONTONIC MP 85W-140	
FUCHS	TITAN HYD 1030 • AGRIFARM STOU MC 10W-30 • AGRIFARM STOU MC 10W-30 • AGRIFARM UTTO MP • PLANTO HYD 40N ***	• AGRIFARM STOU MC 10W-30 • TITAN UNIVERSAL HD	• AGRIFARM GEAR 80W90 • AGRIFARM GEAR 85W-140 • AGRIFARM GEAR LS 90	• AGRIFARM HITEC 2 • AGRIFARM PROTEC 2 • RENOLIT MP • RENOLIT FLM 2 • PLANTOGEL 2-N	• AGRIFARM FLOWTEC 000 • RENOLIT SO-GFO 35 • RENOLIT DURAPLEX EP 00 • PLANTOGEL 00N	• RENOLIT DURAPLEX EP 1	• AGRIFARM GEAR 8090 • AGRIFARM GEAR 85W-140 • AGRIFARM GEAR LS90	
GENOL	HYDRAULIKÖL HLP 32/46/68 HYDRAMOT 1030 MC * HYDRAULIKÖL 520 ** PLANTO HYD 40N ***	MULTI 2030 2000 TC HYDRAMOT 15W-30 HYDRAMOT 1030 MC	GETRIEBEÖL MP 90 HYPOID EW 90 HYPOID 85W-140	MEHRZWECKFETT SPEZIALFETT GLM PLANTOGEL 2 N	GETRIEBEFLEISSFETT PLANTOGEL 00N	RENOPLEX EP 1	HYPOID EW 90 HYPOID 85W-140	
MOBIL	DTE 22/24/25 DTE 13/15	HD 20W-20 DELVAC 1230 SUPER UNIVERSAL 15W-30	MOBILUBE GX 90 MOBILUBE HD 90 MOBILUBE HD 85W-140	MOBILGREASE MP	MOBILUX EP 004	MOBILPLEX 47	MOBILUBE HD 90 MOBILUBE HD 85W-140	
RHG	RENOLIN B 10/15/20 RENOLIN B 32 HVI/46HVI	EXTRA HD 30 SUPER HD 20 W-30	MEHRZWECKGETRIEBEÖLSAE90 HYPOID EW 90	MEHRZWECKFETT RENOLIT MP DURAPLEX EP	RENOSOD GFO 35	RENOPLEX EP 1	HYPOID EW 90	

Company	I				V	VI	VIII	NOTATIONS
SHELL	TELLUS S32/S46/S68 TELLUS T 32/T46	AGROMA 15W-30 ROTELLA X 30 RIMULA X 15W-40	SPIRAX 90 EP SPIRAX HD 90 SPIRAX HD 85/140	RETINAX A ALVANIA EP 2	SPEZ. GETRIEBEFETT H SIMMIA GREASE O	AEROSHELL GREASE 22 DOLIUM GREASE R	SPIRAX HD 90 SPIRAX HD 85W-140	* The international specification J 20 A is necessary for compound operation with wet brake tractors.
TOTAL	AZOLLA ZS32,46,68 EQUIVIZS 32, 46, 68	RUBIA H 30 MULTAGRI TM 15W-20	TOTAL EP 85W-90 TOTAL EP B 85W-90	MULTIS EP 2	MULTIS EP 200	MULTIS HT 1	TOTAL EP B 85W-90	** HLP-(D) + HV hydraulic oils
VALVOLINE	ULTRAMAX HLP 32/46/68 SUPER TRAC FE 10W-30 ULTRAMAX HVL 32 ** ULTRAPLANT 40 ***	SUPER HPO 30 STOU 15W-30 SUPER TRAC FE 10W-30 ALL FLEET PLUS 15W-40	HP GEAR OIL 90 oder 85W-140 TRANS GEAR OIL 80W-90	MULTILUBE EP 2 VAL-PLEX EP 2 PLANTOGEL 2 N	RENOLIT LZR 000 DEGRALLUB ZSA 000	DURAPLEX EP 1	HP GEAR OIL 90 oder 85W-140	*** HLP + HV hydraulic oils with a vegetable oil basis, biodegradable and therefore environmentally friendly.
VEEDOL	ANDARIN 32/46/68	HD PLUS SAE 30	MULTIGRADE SAE 80/90 MULTIGEAR B 90 MULTIGEAR C SAE 85W-140	MULTIPURPOSE	-	-	MULTIGEAR B 90 MULTI C SAE 85W-140	
WINTERSHALL	WIOLAN HS (HG) 32/46/68 WIOLAN HVG 46 ** WIOLAN HR 32/46 *** HYDROFLUID *	MULTI-REKORD 15W-40 PRIMANOL REKORD 30	HYPOID-GETRIEBEÖL 80W-90, 85W-140 MEHRZWECKGETRIEBEÖL 80W-90	WIOLUB LFP 2	WIOLUB GFW	WIOLUB AFK 2	HYPOID-GETRIEBEÖL 80W-90, 85W-140	
MOTOREX	COREX HLP 32 46 68** COREX HLPD 32 46 68** COREX HV 32 46 68** OEKOSYNT 32 46 68***	EXTRA SAE 30 FARMER TRAC 10W/30	GEAR OIL UNIVERSAL 80W/90 GEAR OIL UNIVERSAL 85W/140	FETT 176 GP FETT 190 EP FETT 3000	FETT 174	FETT 189 EP FETT 190 EP FETT 3000	GEAR OIL UNIVERSAL 80W/90 GEAR OIL UNIVERSAL 85W/140	




Attachment variations

The distance between cutting disc and tractor tyres should be as minimal as possible (X1).

Install the console and lower link pins according to the tractor being used.

Adaption to the tractor

1. Measure the distance to the outer sides of the tractor tyres (RA).
2. Install the console accordingly
Pos. A (RA = 1800 bis 2300 mm).
Pos. B (RA = 2000 bis 2600 mm).
3. Insert the lower linkage pins accordingly.




Examples:






Tractor with a width of RA = 1900 mm

- Console in Pos. A
- Distance X1 = +100 mm / +50 mm / 0 mm
 - insert lower linkage pins accordingly (50,51).

Tractor with a width of RA = 2400 mm.




- Console in Pos. B
- Distance X1 = +40 mm / -10 mm / -60 mm
 - insert lower linkage pins accordingly (50,51).












Repairs to the cutter bar

- Markings aligned (K1, K2).
up to 2005 model
(Marking K1 = Centre point on the hub)
from 2006 model
(Marking K1 = Larger countersink when drilling)
- Only screw on nut (M) when there is sufficient thread length (L) to prevent any damage.
- Secure nut (M) against loosening
 - with "Loctite 242" or an equivalent product
 - and centre point (2x)













Assembly instructions

- For easier assembly of the cutting discs please proceed as follows:
 - With the disc's direction of rotation to the left = Marking (K1) at the top
 - With the disc's direction of rotation to the right = Marking (K1) at the bottom



271-08-01






Combination of tractor and mounted implement



The mounting of implements on the front or rear three point linkage shall not result in exceeding the maximum permissible weight, the permissible axle loads and the tyre load carrying capacities of the tractor. The front axle of the tractor must always be loaded with at least 20 % of the unladen weight of the tractor.

Make sure before buying an implement that these conditions are fulfilled by carrying out the following calculations or by weighing the tractor/implement combination.

Determination of the total weight, the axle loads, the tyre load carrying capacity and the necessary minimum ballasting



For the calculation you need the following data:

T_L [kg]	unladen weight of tractor	1	a [m]	distance from centre of gravity for combined front mounted implement/front ballast to front axle centre	2 3
T_V [kg]	front axle load of unladen tractor	1			
T_H [kg]	rear axle load of unladen tractor	1	b [m]	Tractor wheelbase	1 3
G_H [kg]	combined weight of rear mounted implement/rear ballast	2	c [m]	distance from rear axle centre to centre of lower link balls	1 3
G_V [kg]	combined weight of front mounted implement/front ballast	2	d [m]	distance from centre of lower link balls to centre of gravity for combined rear mounted implement/rear ballast	2

- 1 see instruction handbook of the tractor
- 2 see price list and/or instruction handbook of the implement
- 3 to be measured

Consideration of rear mounted implement and front/rear combinations

1. CALCULATION OF MINIMUM BALLASTING AT THE FRONT $G_{V \min}$

Record the calculated minimum ballasting which is needed at the front of the tractor into the table.

$$G_{V \min} = \frac{G_H \cdot (c + d) - T_V \cdot b + 0,2 \cdot T_L \cdot b}{a + b}$$

Front mounted implement

2. CALCULATION OF THE MINIMUM $G_{H \min}$

$$G_{H \min} = \frac{G_V \cdot a - T_H \cdot b + 0,45 \cdot T_L \cdot b}{b + c + d}$$

Record the calculated minimum ballasting which is needed at the rear of the tractor into the table.

3. CALCULATION OF THE REAL FRONT AXLE LOAD $T_{V \text{ tat}}$

(If with the front mounted implement (G_V) the required minimum front ballasting ($G_{V \text{ min}}$) cannot be reached, the weight of the front mounted implement has to be increased to the weight of the minimum ballasting at the front!)

$$T_{V \text{ tat}} = \frac{G_V \cdot (a + b) + T_V \cdot b - G_H \cdot (c + d)}{b}$$

Record the calculated real front axle load and the permissible front axle load of the tractor into the table.

4. CALCULATION OF THE REAL TOTAL WEIGHT G_{tat}

(If with the rear mounted implement (G_H) the required minimum rear ballasting ($G_{H \text{ min}}$) cannot be reached, the weight of the rear mounted implements has to be increased to at least the weight of the minimum ballasting at the rear!)

$$G_{\text{tat}} = G_V + T_L + G_H$$

Record the calculated real and the permissible total weight given in the instruction handbook for the tractor into the table.

5. CALCULATION OF THE REAL REAR AXLE LOAD $T_{H \text{ tat}}$

Record the calculated real and the permissible rear axle load given in the instruction handbook for the tractor into the table.

$$T_{H \text{ tat}} = G_{\text{tat}} - T_{V \text{ tat}}$$

6. TYRE LOAD CARRYING CAPACITY

Record double the value (two tyres) of the permissible load carrying capacity into the table (see for instance documentation provided by the tyre manufacturer).

Table

	Real value according to calculation	Permissible value according to instruction handbook	Double permissible tyre load carrying capacity (two tyres)
Minimum ballasting front/rear	<div style="border: 1px solid black; padding: 5px; display: inline-block;">/ kg</div>	---	---
Total weight	<div style="border: 1px solid black; padding: 5px; display: inline-block;">kg</div>	<div style="border: 1px solid black; padding: 5px; display: inline-block;">kg</div>	---
Front axle load	<div style="border: 1px solid black; padding: 5px; display: inline-block;">kg</div>	<div style="border: 1px solid black; padding: 5px; display: inline-block;">kg</div>	<div style="border: 1px solid black; padding: 5px; display: inline-block;">kg</div>
Rear axle load	<div style="border: 1px solid black; padding: 5px; display: inline-block;">kg</div>	<div style="border: 1px solid black; padding: 5px; display: inline-block;">kg</div>	<div style="border: 1px solid black; padding: 5px; display: inline-block;">kg</div>

The minimum ballasting has to be attached to the tractor either in form of a mounted implement or ballasting weight!

The calculated values must be less or equal (<) the permissible values!

The CE norm is not valid in the United States of America and Canada.



EC Conformity Declaration

Original Conformity Declaration

Name and address of the manufacturer:

**PÖTTINGER Landtechnik GmbH
Industriegelände 1
AT - 4710 Grieskirchen**

Machine (interchangeable equipment):

**mower
Type
Serial no.**

Novadisc 400	
389	

The manufacturer declares that the machines adhere to all relevant provisions in the following EU directive:

machinery 2006/42/EG

In addition to this, the manufacturer also declares adherence to the other following EU directives and/or relevant provisions

Source of applied, harmonised norms:

EN ISO 12100

EN ISO 4254-1

EN ISO 4254-12

Source of applied miscellaneous technical norms and / or specifications:

Person responsible for documentation:

Andreas Gadermayr
Industriegelände 1
A-4710 Grieskirchen

A handwritten signature in black ink, appearing to be 'MB'.

Markus Baldinger,
CTO R&D

A handwritten signature in black ink, appearing to be 'JL'.

Jörg Lechner,
CTO Production

Grieskirchen, 01.08.2016

(D) Im Zuge der technischen Weiterentwicklung arbeitet die PÖTTINGER Landtechnik GmbH ständig an der Verbesserung ihrer Produkte.

Änderungen gegenüber den Abbildungen und Beschreibungen dieser Betriebsanleitung müssen wir uns darum vorbehalten, ein Anspruch auf Änderungen an bereits ausgelieferten Maschinen kann daraus nicht abgeleitet werden.

Technische Angaben, Maße und Gewichte sind unverbindlich. Irrtümer vorbehalten.

Nachdruck oder Übersetzung, auch auszugsweise, nur mit schriftlicher Genehmigung der

PÖTTINGER

Landtechnik GmbH

A-4710 Grieskirchen.

Alle Rechte nach dem Gesetz des Urheberrecht vorbehalten.

(NL) PÖTTINGER Landtechnik GmbH werkt permanent aan de verbetering van hun producten in het kader van hun technische ontwikkelingen. Daarom moeten wij ons veranderingen van de afbeeldingen en beschrijvingen van deze gebruiksaanwijzing voorbehouden, zonder dat daaruit een aanspraak op veranderingen van reeds geleverde machines kan worden afgeleid.

Technische gegevens, maten en gewichten zijn niet bindend. Vergissingen voorbehouden.

Nadruk of vertaling, ook gedeeltelijk, slechts met schriftelijke toestemming van

PÖTTINGER

Landtechnik GmbH

A-4710 Grieskirchen.

Alle rechten naar de wet over het auteursrecht voorbehouden.

(P) A empresa PÖTTINGER Landtechnik GmbH esforçase continuamente por melhorar os seus produtos, adaptando-os à evolução técnica.

Por este motivo, reservamos o direito de modificar as figuras e as descrições constantes no presente manual, sem incorrer na obrigação de modificar máquinas já fornecidas.

As características técnicas, as dimensões e os pesos não são vinculativos.

A reprodução ou a tradução do presente manual de instruções, seja ela total ou parcial, requer a autorização por escrito da

PÖTTINGER

Landtechnik GmbH

A-4710 Grieskirchen

Todos os direitos estão protegidos pela lei da propriedade intelectual.

(F) La société PÖTTINGER Landtechnik GmbH améliore constamment ses produits grâce au progrès technique.

C'est pourquoi nous nous réservons le droit de modifier descriptions et illustrations de cette notice d'utilisation, sans qu'on en puisse faire découler un droit à modifications sur des machines déjà livrées.

Caractéristiques techniques, dimensions et poids sont sans engagement. Des erreurs sont possibles.

Copie ou traduction, même d'extraits, seulement avec la permission écrite de

PÖTTINGER

Landtechnik GmbH

A-4710 Grieskirchen.

Tous droits réservés selon la réglementation des droits d'auteurs.

(E) La empresa PÖTTINGER Landtechnik GmbH se esfuerza continuamente en la mejora constante de sus productos, adaptándolos a la evolución técnica. Por ello nos vemos obligados a reservarnos todos los derechos de cualquier modificación de los productos con relación a las ilustraciones y a los textos del presente manual, sin que por ello pueda ser deducido derecho alguno a la modificación de máquinas ya suministradas.

Los datos técnicos, las medidas y los pesos se entienden sin compromiso alguno.

La reproducción o la traducción del presente manual de instrucciones, aunque sea tan solo parcial, requiere de la autorización por escrito de

PÖTTINGER

Landtechnik GmbH

A-4710 Grieskirchen.

Todos los derechos están protegidos por la ley de la propiedad industrial.

(GB) Following the policy of the PÖTTINGER Landtechnik GmbH to improve their products as technical developments continue, PÖTTINGER reserve the right to make alterations which must not necessarily correspond to text and illustrations contained in this publication, and without incurring obligation to alter any machines previously delivered.

Technical data, dimensions and weights are given as an indication only. Responsibility for errors or omissions not accepted.

Reproduction or translation of this publication, in whole or part, is not permitted without the written consent of the PÖTTINGER

Landtechnik GmbH

A-4710 Grieskirchen.

All rights under the provision of the copyright Act are reserved.

(I) La PÖTTINGER Landtechnik GmbH è costantemente al lavoro per migliorare i suoi prodotti mantenendoli aggiornati rispetto allo sviluppo della tecnica.

Per questo motivo siamo costretti a riservarci la facoltà di apportare eventuali modifiche alle illustrazioni e alle descrizioni di queste istruzioni per l'uso. Allo stesso tempo ciò non comporta il diritto di fare apportare modifiche a macchine già fornite.

I dati tecnici, le misure e i pesi non sono impegnativi. Non rispondiamo di eventuali errori. Ristampa o traduzione, anche solo parziale, solo dietro consenso scritto della

PÖTTINGER

Landtechnik GmbH

A-4710 Grieskirchen.

Ci riserviamo tutti i diritti previsti dalla legge sul diritto d'autore.



PÖTTINGER

Landtechnik GmbH

A-4710 Grieskirchen
Telefon: +43 7248 600-0
Telefax: +43 7248 600-2513
e-Mail: info@poettinger.at
Internet: <http://www.poettinger.at>

PÖTTINGER Deutschland GmbH Verkaufs- und Servicecenter Recke

Steinbecker Strasse 15
D-49509 Recke
Telefon: +49 5453 9114-0
Telefax: +49 5453 9114-14
e-Mail: recke@poettinger.at

PÖTTINGER Deutschland GmbH Servicecenter Landsberg

Spöttinger-Straße 24
Postfach 1561
D-86 899 LANDSBERG / LECH
Telefon:
Ersatzteildienst: +49 8191 9299 - 166 od. 169
Kundendienst: +49 8191 9299 - 130 od. 231
Telefax: +49 8191 59656
e-Mail: landsberg@poettinger.at

PÖTTINGER France S.A.R.L.

129 b, la Chapelle
F-68650 Le Bonhomme
Tél.: +33 (0) 3 89 47 28 30
e-Mail: france@poettinger.at